



Ramp

How to Guide

Program RFID tags
using Fast Tagging

1 Log into the Device

Enter your given username and password into the respective fields. Tap on the **Login** button to access the device.




2 Open Tagging

To navigate to the fast tagging function, tap on the **Tagging** tile.



3 Open Fast Tagging

Continue navigating to the fast tagging function by tapping on the **Fast Tagging** tile.




4 Scan Barcode

To start, you will need to scan a product's barcode. To scan the barcode, **tap the trigger quickly** and **aim the red light at the product's barcode**.



5 SKU Information

Once a barcode has been scanned, information about the barcode will be shown. A green indicator will appear to let the user know they've successfully scanned a barcode.



6 Programming


Once you've successfully scanned a barcode, you can now program an RFID tag.

To program the RFID, **hold the handheld against the RFID tag** and **tap the trigger quickly**.



7 Confirmation

A green indicator and an audible cue will appear to show the RFID tag was programmed correctly.



8 Resetting

Once you've programmed an RFID tag, you can move to the next product barcode and start from step 4.

You can also reset the interface by pressing **Reset**.

